

# HOW TO FIND A FILTER CARTRIDGE REPLACEMENT

## BY SIZE:

1. Measure the outside diameter of the cartridge (in inches, +/- 1/32").
2. Measure the cartridge length (in inches, +/- 1/16") including end caps but excluding any handles or other extensions. We recommend measuring through the center (if possible) rather than along the outside edge.
3. Identify the cartridge outside edge end-cap configuration. If the top and/or bottom is open, measure the inside diameter (in inches, +/- 1/32") of the top and/or bottom.
4. Count the number of pleats (+/- 2) and note whether there is a center core or not.

## BY ITEM / MODEL NUMBER:

5. Record the OEM name and model of the filter the cartridge came out of (if possible). There may also be a Unicel or Pleatco number as well.

The information gathered in 1-5 above can then be used to identify a proper replacement.

